



**NX80**  
PRECISE BASS

User's  
Manual

Thank you for your  
NoiseHush NX80 purchase.

### Selecting Ear Gels

The perceived sound quality and bass performance of the headphones depends to a large extent on the correct fit of the headphones in the ear. For best sound enjoyment, please use the supplied ear gels. Choose from 3 different sizes for maximum comfort.

### Playing Your Music

Plug the NX80 into your devices 3.5mm jack.

### Answering Calls

Press the function button to answer and end calls.

### Storing your NX80


When not in use, simply store in the provided protective pouch.

### Cleaning

Use a dry cloth to clean the in-ear headphones from time to time.

### Warranty

With one of the lowest return rates in the industry we pride ourselves on the quality of our product. Additionally we offer a Standard 1 Year Limited Warranty.

 Attention – Using your NX80 at high volume can lead to hearing defects.

[www.noisehush.com](http://www.noisehush.com)